

## 2006 Scheduled Maintenance Intervals

Miles (in thousands)	5/25/45/65/85/105	15/55/95	35/75
Kilometres (in thousands)	8/40/70/100/130/160	25/85/145	55/115
Engine Oil – change oil and replace filter			
Wiper/Washer/Headlight Washer – check adjustment and function, add fluid if necessary			
Tires and Spare – check for wear and damage, check pressure – check for wear and damage, check pressure and renewal date of tire set (where applicable)			
Tires – rotate	5K only		
Service Reminder Display – reset			
Brake System – check for damage, leaks, pad thickness, fluid level			
Wiper Arm Pivot Points – lubricate			
Cooling System – check level, add if necessary			
Exhaust System – check for damage, leaks			
Engine On Board Diagnostics – check fault memory			
Engine Compartment – check for leaks			
Battery – check electrolyte level and add if necessary			
Dust and Pollen Filter – replace			
Automatic Transmission and Final Drive – check for leaks			
Manual Transmission and Final Drive – check for leaks			
DSG (direct shift gearbox) – change oil and replace filter element			A3, TT only
Haldex Clutch – change oil		TT only	A3, TT only
– change filter			TT only
Sunroof – clean guide rails and lubricate rails with grease spray			
Front and Rear Axle – check for excessive play, check dust seals on ball joints and tie rod ends			
Lights – check all lights, check headlight adjustment		TT, A4 Cab, A8 only	
Drive Shaft Boots – check			
Doors – lubricate doors, check straps		TT, A4 Cab, A8 only	
Spark Plugs – replace at 35,000 miles or 3 years, whichever occurs first. Then, every 40,000 miles or 3 years, whichever occurs first.			35K only: 1.8T, 3.0L, 3.2L VR6, 6.0L
– replace at 55,000 miles or 6 years, whichever occurs first. Then, every 60,000 miles or 6 years, whichever occurs first.		55K only: except 1.8T, 3.0L, 3.2L VR6, 6.0L	
– replace at 75,000 miles			75K only: 1.8T, 3.0L, 3.2L VR6, 6.0L only
Continuously Variable Transmission (multitronic) – change ATF			
Power Steering Fluid – check, add if necessary			
Air Cleaner – clean housing, replace filter element		55K only: A3, A4, A6, A8 4.2L	TT, A8 6.0L only
Ribbed V Belt – check condition			35K only: A8 6.0L 75K only: A8 6.0L, 2.0TFSI, 3.0L, 3.2L
– r eplace			75K only: except 2.0TFSI, 3.0L, 3.2L, 6.0L
Snow Screen for Air Cleaner – clean		A4, A6 only	A4, A6 only
Underbody – check for damage and leaks			
Road Test – check braking, kick-down, steering, electrical, heating and ventilation systems, air conditioning, shift lock operation and power accessories			
Rear Lid Hinges – lubricate		A8 only	A8 only
Timing Belt – replace			75K only: 1.8T, 3.0L, A8 4.2L

At 110K miles (175km) replace timing belt (2.0TFSI engine only). Check condition of timing belt tensioning system, dampening pulleys, and idler pulleys and replace if necessary (2.0TFSI engine only).

Brake Fluid – replace every 2 years regardless of mileage.

Cloth Top – check function and rollover protection every 2 years regardless of mileage (Audi A4 Cabriolet only).